



Lazy Susan 20in Full Round White

Part Number: 04-1505

Lazy Susan - Plastic Round

Plastic Round Shaped

Basket Bottom Type	Plastic
Diameter	20 in
Finish	White
Frame Finish	Chrome
Material	Plastic
Shape	Round

Product Description

The full round circle Lazy Susan is lightweight, durable, and easy to clean, making it an ideal, low cost corner storage solution.


Product Advantages

- Ideal for 45-degree corner cabinets
- · Available in multiple diameters
- Durable white plastic with chrome finish steel pole
- Telescoping pole is height adjustable
- · Independent adjustment of shelves
- · Simultaneous swiveling of trays
- Bulk Pack offers better price, but no broken boxes
- · Load capacity: 16kg (35lbs) per shelf

Technical Documents

Planning Minimum Interior Cabinet Dimensions mm/inch

Ø x H Ø x 533 - 838xmm (Ø x 21 - 33")





(21 - 33")


Ø Diameter Part#

711mm (28") 04-1523

View this product online at https://marathonhardware.com/pd/04-1505



Technical Documents



Mechanism Height 533-838 mm (21" - 33")

View this product online at https://marathonhardware.com/pd/04-1505



Printed on: 2024-May-

Technical Documents

ISO 9001 Certification




Round Lazy-Susan Rotating Tray




Instructions Installation

This Installation Instruction document is applicable for:
BPS-0232 / BP0-0228 / 24 / 20 / 18 Round Polymer Lazy Susan







1 telescopic chrome post with pre-installed adjustment ring B

- 2 positioning supports: A(top) and D (bottom)
- 2 Round shelves
- 2 supporting cones C
- Mounting hardware

Tools required for mounting: Screwdriver: Philips or square drive

- Mounting Steps Instructions:

 1. Locate cabinet center for placement of lower positioning support D. Insure that you have adequate clearance for free rotation of tray after installation.
 - Upper positioning support A must be placed directly above the lower. To achieve this, you should check vertical alignment with level or plumb line.
- 2. Remove plastic cones C from the chrome post and insert into center hole of each shell from the bottom.
 - Note: make sure that you line up the wide rib with the wide slot. To ensure a proper fit, you must push the cone into the center hole until it snaps into the locked position.
- Slide both shelves back onto the chrome post, and then insert the bottom of post into lower positioning support D.
- Insert telescoping portion of chrome post into the top positioning support \mathbf{A} , and tighten set screw \mathbf{B} to secure the assembly
- 5. Adjust shelf height to desired level and fix into position by tightening the two set screws for each
- For BPS-0232, further tighten set screws to firmly secure the extra weight of the shelves.

Armotec inc.

View this product online at https://marathonhardware.com/pd/04-1505