
Part#
086-Z1ZXE-MB
086-Z2ZXE-MB
086-Z3ZXE-MB
086-Z4ZXE-MB
086-Z5ZXE-MB
0FE-AMXXI-MB
MAR-THEX-3MM




- Corners are not directionally specific. Use 1 of each type (A/B or C/D) at each ends of bar that connects in between. See assembly examples below and at right for further direction.
- Screws are included with Corner Connectors. Extras intended for spares.

## **Basic Assembly with 3-Way Corner Connectors**



## **Advanced Assembly with 4-Way Corner Connectors**



## **Advanced Assembly with 5-Way Corner Connectors**

